



A **VANTAGE** Company

Bulletin #1187

GT-Series Geared Traction Machine Installation Manual



*Rope Gripper® not included

Hollister-Whitney Elevator Co. LLC

#1Hollister-Whitney Parkway

Quincy, IL 62305

Phone 217.222.0466 • Fax 217.222.0493

8/4/2023



WARNING

This installation manual is intended for the use of qualified and authorized elevator personnel ONLY. For your safety and the safety of others, do not attempt ANY procedure that you are not qualified and authorized to perform. Recommended procedures must be done in accordance with the applicable rules of the latest edition of the National Electrical Code; the latest edition of ASME A17.1; and all governing local codes. Every attempt has been made to ensure that this guide is accurate and up to date. Hollister-Whitney Elevator Co. LLC assumes no liability for consequences resulting from any error or omission. Please notify Hollister-Whitney Elevator Co. LLC regarding any difficulties with this manual.

Contents

1 Introduction.....	1-1
1.1 Description.....	1-1
1.2 Warranty Information	1-1
1.3 Codes and Standards	1-1
1.4 General Specifications	1-2
2 Safety Precautions	2-1
2.1 Terms in This Manual	2-1
2.2 General Safety	2-1
2.3 Electrical Safety	2-1
2.4 Electrical Hazards	2-2
2.5 Mainline Disconnect.....	2-2
2.6 Test Equipment Safety.....	2-2
2.7 When Power Is On.....	2-2
2.8 Product Specific Warnings.....	2-2
3 Arrival of the Equipment	3-1
3.1 Receiving.....	3-1
3.2 Handling.....	3-2
3.3 Hoisting.....	3-2
3.4 Storage	3-4
3.5 Moisture, Condensation	3-4
4 Installation	4-1
4.1 Overview.....	4-1
4.2 Machine Mounting.....	4-2
4.3 Electrical Connections	4-4
4.4 Startup	4-5
4.5 Rope Retainer Installation.....	4-7
4.6 Rope Gripper Mounting.....	4-17
5 Adjustments.....	5-1

5.1	Brake Torque Adjustment	5-1
5.2	Brake Shoe Gap Adjustment.....	5-1
5.3	Brake Switch Adjustment	5-1
5.4	Brake Solenoid Plunger/Adjustment Bolt Gap Adjustment.	5-2
5.5	Worm/Gear Backlash Adjustment	5-3
5.6	Worm/Gear Pattern Adjustment	5-3
6	Maintenance	6-1
6.1	General	6-1
6.2	Cleaning.....	6-1
6.3	Recommended Inspection / Maintenance	6-2
6.4	Other Items / Comments	6-4
7	Service / Replacement.....	7-1
7.1	General Assembly Drawings.....	7-2
7.2	Assembly Replacement Kits	7-27
7.3	Individual Component Replacement Parts	7-28
7.4	Gripper Mounting Equipment Assembly Drawings.....	7-32
8	Appendix	8-1
8.1	Encoder Supplier Data	8-1
8.2	Brake Solenoid CSA Certification	8-5

Section

1

1 Introduction

1.1 Description

Thank you for choosing the Hollister-Whitney Elevator Company's (HVEC), GT-Series Geared Traction Machine.

The GT-series machines are worm and gear type machines which are designed for use in machine room configurations with VVVF controls.

The GT-series braking is supplied by a spring activated drum brake which is deactivated by a brake solenoid assembly.

1.2 Warranty Information

All parts and equipment manufactured by HVEC are guaranteed against defects in material and workmanship for a period of one (1) year from the date of shipment.

Warranty covers only the repair or replacement of parts, F.O.B. our factory, upon determination by inspection at our factory that warranty is applicable.

Equipment and components not of our manufacture are warranted only to the extent of the original manufacturer's warranty.

Our warranty specifically does not include any other incidental liability or expense such as transportation, labor, and unauthorized repairs.

1.3 Codes and Standards

The GT-series machines are designed to comply with ASME A17.1/CSA B44 code.

The motors are designed with class F insulation minimum and have been approved by and carry a CSA approved label.

The brake solenoids have been approved by and carry a CSA approved label.

The brake switches have been approved by and carry a CSA approved label.

1.4 General Specifications

1.4.1 Application Range and Mechanical Specifications

Model →	GT11OH / GT11BS / GT11OD						GT31OH / GT31BS / GT31OD			
Drive Sheave Diameter (in.)	22"		26"		30"		26"		30"	
	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.
1:1 – Speed (fpm)	100	500	100	500	100	500	100	500	100	500
1:1 – Capacity (lbs.)	1,000	3,000	1,000	3,000	1,000	3,000	2,000	6,000	2,000	4,500
2:1 – Speed (fpm)	50	250	50	250	50	250	50	250	50	250
2:1 – Capacity (lbs.)	1,000	6,000	1,000	6,000	1,000	6,000	4,000	12,000	4,000	9,000
Number of Ropes (up to)	Qty.	Size	Qty.	Size	Qty.	Size	Qty.	Size	Qty.	Size
	9	3/8"	9	3/8"	9	3/8"	9	3/8"	9	3/8"
	7	1/2"	7	1/2"	7	1/2"	7	1/2"	7	1/2"
	-	-	6	5/8"	6	5/8"	6	5/8"	6	5/8"
Approximate Machine Weight (lbs.) (does not include motor)	OH = 1,650 BS = 1,975 OD = 2,750		OH = 1,700 BS = 2,025 OD = 2,800		OH = 1,800 BS = 2,125 OD = 2,900		OH = 2,100 BS = 2,435 OD = 3,151		OH = 2,200 BS = 2,535 OD = 3,251	
Approx. Motor Weight by Frame (lbs.)	284TC: 350 286TC: 400 324TC: 450 326TC: 610 365TC: 690									
Max. Drive Sheave Shaft Load (lbs.)	17,000						25,000			
Factory Brake Torque Setting (ft*lbs.)	160 to 176						212 to 220			
Approx. Gear Case Oil Capacity (gal)	2						2.5			
Oil Grade	Mobil SHC 636 is recommended									
Operating Environment	Machine Room Ambient Temperature: 35°F to 104°F (1.7°C to 40°C) Max. Relative Humidity: 85% at 20°C (68°F) Non-Condensing Storage Temperature: -20°C to +60°C (-4°F to +140°F) Altitude: Sea Level to 2000m (6561 ft) Above Sea Level									

Table 1-1

1.4.2 Brake System Electrical Specifications

Model →	All
Brake Solenoid Electrical Data	<u>Version A:</u> Pick: 190Vdc, ≤ 2.5A, Hold: 80Vdc, ≤ 1A, Resistance: 98±5%Ω (20°F) <u>Version B:</u> Pick: 110Vdc, ≤ 3.6A, Hold: 60Vdc, ≤ 2A, Resistance: 39±5%Ω (20°F) Starts Per Hour: 180 Duty Cycle: 60%
Brake Switch Electrical Data	<u>AC Rating:</u> 125V/15A, 250V/15A, 480V/15A <u>DC Rating:</u> 125V/0.5A, 250V/0.25A

Table 1-2

1.4.3 Estimated Motor and Gear Box Heat Loss

Model→	All						
Motor HP ↓	*Estimated Motor BTU/HR ↓	*Estimated Gear Box BTU/HR					
		GT11 Gear Ratios			GT31 Gear Ratios		
		<u>49:1</u>	<u>49:2</u>	<u>49:3</u>	<u>71:1</u>	<u>71:2</u>	<u>71:3</u>
5	998	855	489	366	-	-	-
7.5	1113	1282	733	550	-	-	-
10	1336	1710	977	733	1873	896	651
12.5	1740	2137	1221	916	2341	1120	814
15	1868	2565	1466	1099	2809	1343	977
20	2722	3420	1954	1466	3745	1791	1303
25	3089	4275	2443	1832	4682	2239	1628
30	3387	5130	2931	2198	5618	2687	1954
35	3650	5984	3420	2565	6554	3135	2280
40	3867	-	-	-	7491	3583	2605
45	4289	-	-	-	8427	4030	2931
50	5275	-	-	-	9364	4478	3257
*Estimate Assumptions: 40% Counterweight; 60% Duty Cycle, HW Internal Loading Spectrum Total Estimated Machine BTU/HR = Estimated Motor BTU/HR + Estimated Gear Box BTU/HR							

Table 1-3

Section

2

2 Safety Precautions

Read this section before any work is performed on elevator equipment.

*** IMPORTANT** —The procedures contained in this manual are intended for the use of qualified elevator personnel. In the interest of your personal safety and the safety of others, do NOT attempt ANY procedure that you are NOT qualified to perform.

All procedures must be done in accordance with the applicable rules in the latest edition of the National Electrical Code; the latest edition of ASME A17.1; and any governing local codes.

2.1 Terms in This Manual

⚠ CAUTION: Caution Statements identify conditions that could result in damage to the equipment or other property if improper procedures are followed!

⚠ WARNING: Warning Statements identify conditions that could result in personal injury if improper procedures are followed!

2.2 General Safety

Specific warnings and cautions are found where they apply, and DO NOT appear in this summary.

2.3 Electrical Safety

All wiring must be in accordance with the National Electrical Code and must be consistent with all state and local codes.

2.4 Electrical Hazards

Electric shocks can cause personal injury or loss of life. Circuit breakers, switches and fuses may NOT disconnect all power to the equipment. Always refer to the wiring diagrams. Whether the A/C supply is grounded or not, high voltage will be present at many points.

2.5 Mainline Disconnect

Unless otherwise suggested, always turn OFF. Lock and Tag out the mainline disconnect to remove power from the equipment.

2.6 Test Equipment Safety

Always refer to manufactures' instruction book for proper test equipment operation and adjustments.

Megger testing, or buzzer type continuity testers, can damage electronic components. Connection of devices such as voltmeters on certain low-level analog circuits may degrade electronic system performance. Always use a voltmeter with a minimum impedance of 1M Ohm/Volt. A digital voltmeter is recommended.

2.7 When Power Is On

Dangerous voltages exist at several points in some products. To avoid personal injury, do NOT touch exposed electrical connections or components while power is On.

2.8 Product Specific Warnings

WARNING

GT-series machines MUST be balanced during hoisting. See paragraph 3.3 for proper lifting configurations.

WARNING

Hang the elevator car before removing ANY bolts. Failure to do so may result in severe injury and equipment damage.

Section

3

3 Arrival of the Equipment

3.1 Receiving

Immediately upon arrival of the machine, visually inspect the entire machine for any external damage. If any damage incurred in transit is found, make notice of the claim in the presence of the carrier and notify HVEC. If necessary, do not put these machines into operation without first consulting HVEC.

If the machine has gotten wet during transportation, make notice of the claim in the presence of the carrier and notify HVEC.

3.1.1 Inspect Machine Data Tag

Check the Machine Data tag to ensure the machine conforms to the order documentation. The machine data tag is located on the of of the brake housing as shown in Figure 3-1.




Figure 3-1: Machine Data Tag

3.1.2 Inspect Motor Data Tag

Check the Motor Data Tag to ensure the motor conforms to the order documentation and matches the requirements of the controller. See Figure 3-2. The Contract Number on the Machine Data Tag and the Motor Data Tag should agree. The motor data tag is located near the motor supplier Data Tag on the motor housing. The Hollister-Whitney Motor Data Tag contains the electrical data related to that specific contract/installation.

3.1.3 Inspect Traction Wheel Groove Size and Groove Quantity

● HOLLISTER-WHITNEY AC MOTOR CONTRACT DATA ●		
HWECC CONTRACT NO:		
↓ CONTRACT SPECIFIC MOTOR DATA ↓		
HWECC P/N:	HP:	RPM:
VOLTS:	FL AMPS:	

Figure 3-2: Motor Data Tag

Check the traction wheel to ensure that the groove size and groove quantity conform to the order documentation.

3.2 Handling

The machine will be delivered on a wooden pallet. It can be left on the pallet and moved with a standard fork truck or pallet jack.

3.3 Hoisting

The machine can weigh as much as 3950 lbs. (1792 kg). When the machine is removed from the pallet, it must be lifted by using the hoisting eyebolt holes in the base.

When lifting the machine, pull straight up on the hoisting eyebolts using a spreader beam or other suitable rigging apparatus to prevent damage to or failure of the eyebolts, which could result in dropping the machine.

WARNING

Use only the hoisting method shown when lifting the machine! Do not use any other machine component to lift the machine! Lifting the machine by any other component will result in damage to the machine or possible failure of the component resulting in the machine falling from the hoisting system!

Follow all the necessary precautions to avoid damage to the machine or risk to personnel when moving or hoisting the machine.




Figure 1-3: Proper Hoisting Illustration

The motor must be removed to allow access to the holes provided for the eyebolt.




Figure 3-4: Motor Removal Illustration

For a video on disassembly and reassembly of the motor, please go to the Hollister-Whitney Channel on YouTube. Scan the following QR code for direct access to the video:



3.4 Storage

During storage in a warehouse or on the elevator job site, precautions must be taken to protect the machine from dust, dirt, moisture, metal shavings and temperature extremes.

For short term storage, place the machine in a warm, dry and clean environment.

Protect the machine from harsh weather conditions and temperature variations that can lead to condensation.

Protect from dust and metal shavings.

For longer term storage, follow the recommendations above plus; place the machine in a sealed, waterproof enclosure. Add a dehydrating packet that is sized for the enclosure's volume and humidity level.

3.5 Moisture, Condensation

Before installing the machine, and before any voltage is applied, check the machine for condensation, or any evidence of moisture or water. If any evidence of wetness is found, contact HWEC for drying instructions.

After the machine has been dried per factory instructions, it will be necessary to verify the insulation between each coil phase and earth ground. Using an insulation tester (or megohm-meter) check the insulation resistance at 500VDC. The resistance should be *NO LESS* than 100 Mohm.

Section

4

4 Installation

4.1 Overview

The GT-series machine is a worm and gear driven traction machine.

The machine braking is provided by a drum type brake system actuated (set) mechanically by springs and deactivated (picked) with a brake solenoid assembly.




Figure 2-1: Machine Components

The following is a list of major components of the GT-series machines. Along with a brief description of their functions, there is an overview of some of the critical adjustments and maintenance information. See the Installation and Maintenance sections for more detail.

1. **Motor** - The motor connects to the machine via flexible motor coupler, which in turn, rotates the worm gear of the machine.

2. **Encoder** – (Behind Cover) This device is directly coupled to the shaft of the motor and thereby the machine. It is provided to give the absolute speed feedback of the machine to the inverter drive system and to the elevator controller.
3. **Drum Brake** – This assembly is used to prevent the elevator from moving when the car is at rest. Springs provide force to engage the brake shoes on the drum.
4. **Base Assembly** – Supports the machine and mounts the machine to the structure.
5. **Sheave Guard/Rope Retainer** – Provides rope retention to the traction sheave and prevents contact with moving hoist ropes after rope installation.
6. **Traction Sheave** – Provides tractive effort to the hoist ropes to move the car and counterweight. The grooves in the traction sheave provide traction between the sheave and the hoist ropes
7. **Brake Solenoid** - Power applied to the solenoid holds the brake open to allow movement.
8. **Nameplate** – Displays the machine rated data and factory serial number.

4.2 Machine Mounting

Before hoisting the machine into place, verify all the hoisting equipment is rated for the weight of the machine. See Section 1.4.1 to determine the machine weight with and without motor.

Provide a level, structurally supported (rated for the load on the machine) machine space with proper clearance around the machine for maintenance and adjustments.

This machine is primarily intended to be mounted in traditional overhead applications with down-pull forces on the traction sheave.

4.2.1 Overhead Mounting

Anchor the machine to the structural support surface using the (4) mounting hole locations in the base. The hardware required to anchor the machine to the support surface should be at least 3/4" diameter, grade #5 minimum, with standard washers. Hardware adhering to ASME A325 is also suitable.

Note - Due to the varying mounting surface thicknesses, no mounting hardware is shipped with the machine.



Figure 4-2: Overhead Machine

4.2.2 Basement Set Mounting

When used in a basement application, the machine must be mounted to a specially designed tie-down foundation (designed and supplied by others) that will withstand the up-pull forces generated.

Refer to all applicable building codes and ASME A17.1 when selecting hardware to anchor the machine to the structural supports in an up-pull application.

Use the more stringent criteria between the building codes, ASME-A17.1 and the minimum hardware grades identified above.




Figure 4-3: Basement Set Machine

4.2.3 Overhead Deflected Mounting

When used in an overhead deflected application, the machine must rest on suitable support such as structural framing, or a specially designed tie-down foundation (designed and supplied by others) and withstand the up-pull forces generated.

Refer to all applicable building codes and ASME A17.1 when selecting hardware to anchor the machine to the structural supports in such an application.

Use the more stringent criteria between the building codes, ASME-A17.1 and the minimum hardware grades identified above.



Figure 4-4: Overhead Deflected Machine

4.3 Electrical Connections

⚠ WARNING

Before performing any electrical connections, make sure that power supply is turned off. Only then proceed with connecting electrical leads to power supply. Never work in the machine electrical enclosure while power supply is on!

Direct connection to the three-phase power is forbidden as it may destroy the motor.

4.3.1 Brake Switch and Brake Solenoid

The brake switch system has been designed to wire the switches in either the normally open or normally closed position depending on the installers/controller preference. Please see the following electrical circuit diagram for the wiring of the brake switch and brake solenoid.




Figure 4-5: Brake Switch and Brake Solenoid Electrical Schematic

4.3.2 Machine To Power Source Wiring

Please refer to the motor manufacturer and controller manufacturer documentation for recommended wiring.

4.3.3 Encoder Connection

The encoder is located behind the protective cover located on the end on the motor. Connect the encoder per the suppliers' instructions which are located in the appendix of this manual.

4.4 Startup

4.4.1 General Machine Cleanliness / Examination

Inspect the overall cleanliness of the machine and perform an overall general examination of the machine looking for any damaged components. Pay particular attention to brake arms and brake arm pins to ensure that all of the hardware is present.

4.4.2 Brake Drum Cleanliness

⚠ WARNING

The cleanliness of the brake drum is critical to the proper functioning of the brake system. The brake drum surface should be examined and clean thoroughly.

4.4.3 Brake Burnishing

As the brake torque is factory set, brake burnishing is generally not required on initial start-up. Burnishing may only be required in some instances.

4.4.4 Manual Brake Release

⚠ WARNING

The unimpeded functioning of the brake arm and brake solenoid is critical to the proper functioning of the brake system.

To ensure there are no issues with the proper functioning of the brake arms. Use the manual brake release handle to disengage the brake shoe from the brake drum. The handle should be rotated clockwise and counterclockwise several times to ensure complete range of motion.

The manual brake release handle must be removed from the brake assembly prior to normal elevator operation.





Figure 4-6: Manual Brake Release

4.4.5 Verify Brake Intact Seals

Verify that brake tamper resistant paint has not been disturbed on the brake seals.

4.4.6 Motor Related Controller Settings

Verify all the motor related settings in the elevator controller match the information on the machine data tag. There is a “drive learn” tag attached to the motor. This data may be useful when setting up the motor and controller. See Figure 4-7 below.



MOTOR	FREQ	RPM
IG1MTR1030,	60HZ,	875RPM
IG1MTR1031,	60HZ,	1165RPM
IG1MTR1514,	60HZ,	1765RPM
IG1MTR1729,	60HZ,	875RPM
IG3MTR2013,	60HZ,	1165RPM
IG3MTR2030,	60HZ,	875RPM
IG1MTR2504,	60HZ,	1165RPM
IG3MTR3006,	60HZ,	1765RPM
IG3MTR3013,	60HZ,	1170RPM
IG3MTR3014,	60HZ,	1765RPM
IG1MTR3515,	60HZ,	1765RPM
IG3MTR5013,	60HZ,	1170RPM
IG3MTR5014,	60HZ,	1765RPM
IG3MTR5023,	60HZ,	1765RPM

Hallister-Whitney
A LANTAGE Company

P-240

Figure 4-7: Drive Learn Tag

4.4.7 Other

Follow standard elevator industry and governing safety requirements as well as your company’s safety policies and procedures when going through startup procedures.

4.5 Rope Retainer Installation

- Rope retainers are to be installed AFTER installing suspension ropes.
- Ropes are NOT SHOWN in some illustrations in this installation manual but are assumed to be present. Ropes are to be installed before rope retainers.

BEFORE ANY WORK IS DONE:

- Verify Machine
 - Verify the machine is ready for retainer installation.
 - Observe all applicable safety precautions for taking the car out of service and preventing the machine from running during installation of the retainer.
- Verify Retainer Assembly
 - Verify all components are present and the rope retainer can be assembled depending on machine configuration.

4.5.1 Overhead Machine Rope Retainer Installation

4.5.1.1 GT11

- Attach the retainer brackets to the machine housing using the housing guard mounting studs present on the machine housing and the assembly hex nuts.
- Attach the outer retainer plate to the outboard stand using the mounting holes shown in Figure 4-8.
- Attach the inner retainer plate to the retainer brackets as shown in Figure 4-9. Confirm both plates align so that the retainer rods can be assembled. Securely tighten the mounting hardware.
- The plates have been provided with slots cut at 10° intervals from 180° to 140°, along with the outboard stand having a 90° slot and two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 150°, 160°, 170°, and 180° of wrap standard.
- It is recognized that the angle of wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."
- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. make sure the hole position allows running clearance between the rope and retaining rod.



NOTE -

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all hardware is tight. All hardware is Grade 5 and should be tightened to Grade 5 Specifications.

- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine.
- Observe all applicable safety precautions for returning the car to service after installation of the rope retainer.
- See Figure 4-9 for an illustration of a finished assembly.

4.5.1.2 GT31

- Attach the retainer brackets to the machine housing using the tapped holes present on the machine housing.
- Attach the outer retainer plate to the outboard stand using the mounting holes shown in Figure 4-8.
- Attach the inner retainer plate to the retainer brackets as shown in Figure 4-10. Confirm both plates align so that the retainer rods can be assembled. Securely tighten the mounting hardware.
- The plates have been provided with slots cut at 10° intervals from 180° to 140°, along with the outboard stand having a 90° slot and two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 150°, 160°, 170°, and 180° of wrap standard.
- It is recognized that the angle of wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."
- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. make sure the hole position allows running clearance between the rope and retaining rod.



NOTE -

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all hardware is tight. All hardware is Grade 5 and should be tightened to Grade 5 Specifications.
- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine.
- Observe all applicable safety precautions for returning the car to service after installation of the rope retainer.
- See Figure 4-10 for an illustration of a finished assembly.



Figure 4-8: Mounting Holes on GT11 (left) and GT31 (right) Outboard Stands




Figure 4-9: GT11 Bracket Mounting Illustration




Figure 4-10: GT31 Bracket Mounting Illustration

4.5.2 Basement Set Machine Rope Retainer Installation

4.5.2.1 GT11BS

- Attach the BS rope retainer plates to the outboard stands using the provided bolts and the holes shown in Figure 4-11. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- The plates have been provided with slots cut at 20° intervals, along with the outboard stand having a 90° slot and two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 160°, and 180° of wrap standard.
- It is recognized that the angle of wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."
- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. Make sure the hole position allows running clearance between the rope and retaining rod.



NOTE -

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts. In addition, attach three rods to the outboard stand slots illustrated in Figure 4-11. Take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all hardware is tight. All hardware is Grade 5 and should be tightened to Grade 5 Specifications.
- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine.
- Observe all applicable safety precautions for returning the car to service after installation of the rope retainer.
- See Figure 4-12 for an illustration of a finished assembly.

4.5.2.2 GT31BS

- Attach the BS rope retainer plates to the outboard stands using the provided bolts and the holes shown in Figure 4-11. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- The plates have been provided with slots cut at 20° intervals, along with the outboard stand two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 160°, and 180° of wrap standard.
- It is recognized that the angle of wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."

- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. Make sure the hole position allows running clearance between the rope and retaining rod.

**NOTE -**

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts. In addition, attach two rods to the outboard stand slots illustrated in Figure 4-11. Take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all Hardware is tight. All Hardware is Grade 5 and should be tightened to Grade 5 Specifications.
- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine
- Observe all applicable safety precautions for returning the car to service after installation of the guarding.
- See Figure 4-13 for an illustration of a finished assembly.




Figure 4-11: Outboard Stand Mounting Locations GT11 (left) and GT31 (right)




Figure 4-12: GT11 BS Machine Finished Assembly




Figure 4-13: GT31 BS Machine Finished Assembly

4.5.3 Overhead Deflector Rope Retainer

4.5.3.1 GT110D

- Attach the BS rope retainer plates to the outboard stands using the provided bolts and the holes shown in Figure 4-14. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- Attach the OD rope retainer brackets to the deflector pillow blocks as shown in Figure 4-15 using the provided hardware.
- Attach the OD rope retainer plates to the rope retainer brackets. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- The BS plates have been provided with slots cut at 20° intervals, along with the outboard stand having a 90° slot and two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 160°, and 180° of wrap standard. The OD plates have been provided with slots cut at 15 degree intervals from 90° to 60° and 0° to 30° to accommodate retainer rods. This allows for 90°, 75°, or 60° of wrap standard.
- It is recognized that the angle of wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."
- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. Make sure the hole position allows running clearance between the rope and retaining rod.



NOTE -

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts. In addition, attach three rods to the Outboard Stand slots illustrated in Figure 4-14. Take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all Hardware is tight. All Hardware is Grade 5 and should be tightened to Grade 5 Specifications.
- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine
- Observe all applicable safety precautions for returning the car to service after installation of the guarding.
- See Figure 4-16 for an illustration of the finished assembly.

4.5.3.2 GT310D

- Attach the BS rope retainer plates to the outboard stands using the provided bolts and the holes shown in Figure 4-14. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- Attach the OD rope retainer brackets to the deflector pillow blocks as shown in Figure 4-15 using the provided hardware.
- Attach the OD rope retainer plates to the rope retainer brackets. Confirm the outer edges of the retainer plates align so that the retainer rods can be inserted through both plates. Securely tighten the bolts.
- The BS plates have been provided with slots cut at 20° intervals, along with the outboard stand having two 20° slots, to accommodate the retainer rods. This configuration allows for a 140°, 160°, and 180° of wrap standard. The OD plates have been provided with slots cut at 15-degree intervals from 90° to 60° and 0° to 30° to accommodate retainer rods. This allows for 90°, 75°, or 60° of wrap standard.
- It is recognized that the Angle of Wrap may fall between these standard positions, and A17/B44 code (8.4.3.1.4 (b)) states that "... a restraint is located at each end of the arc of contact."
- As necessary, drill a 9/16" (0.5625") hole at the end of the arc of contact. Make sure the hole position allows running clearance between the rope and retaining rod.



NOTE -

RUNNING CLEARANCE RULE OF THUMB: ROPE TO RETAINING ROD CLEARANCE SHOULD NEVER BE GREATER ½ (50%) OF ROPE DIAMETER.

- Attach the retaining rods to the retainer plate using the provided bolts. In addition, attach two rods to the outboard stand slots illustrated in Figure 4-14. Take care to maintain the parallelism (squareness) of the plates with each other.
- When all rods are in place use a convenient shim material to set rope to retaining rod clearance per the **NOTE** above.
- Confirm all Hardware is tight. All Hardware is Grade 5 and should be tightened to Grade 5 Specifications.
- Confirm all work-related material (shims, packaging, tools, etc) is clear of the machine.
- Observe all applicable safety precautions for returning the car to service after installation of the guarding.
- See Figure 4-17 for an illustration of the finished assembly.




Figure 4-14: Outboard Stand Mounting Locations GT11 (left) and GT31 (right)




Figure 4-15: Pillow Block Mounting Locations




Figure 4-16: Finished GT11 Assembly




Figure 4-17: Finished GT31 Assembly

4.6 Rope Gripper Mounting

Before installation of the rope gripper do the following:

- Wear proper PPE (Personal Protective Equipment).
- Inspect tools to ensure they are in good condition and proper working order.
- Read and understand all instructions prior to proceeding.
- Follow standard elevator industry and governing safety requirements.
- Verify Machine
 - Verify the machine is ready for rope gripper installation.
 - Observe all applicable safety precautions for taking the car out of service and preventing the machine from running during installation of the rope gripper.
- Verify rope gripper assembly.
 - Verify all components are present and the rope gripper can be assembled depending on machine configuration.
 - Confirm that the rope gripper assembly is correct for the machine application and configuration.
 - Verify any non-standard rope gripper mounting angles and/or brackets are available as applicable. See Figure 4-18.
 - Verify the proper rope gripper manual is available to reference.
- Determine the rope drop location (matching the existing drop or refer to applicable job layouts) by using plum lines or laser means.
- Confirm that the assembly will have adequate clearance when positioned in line with the required rope drop.
- Prior to the installation of the assembly, plan and prepare for the electrical and/or conduit routing.
- Ensure that electrical routing will not interfere with the operation, maintenance, or removal of the assembly.
- See section 7.4 for prints of gripper mounting angles.

Machine	Machine Type	Gripper Type	Required Gripper Mounting Angles	Required Gripper Bracket
GT11	OH	620L	620L-041	N/A
		622L	622L-041	N/A
		620H	620H-041	N/A
		622H	622H-041	N/A
	OD	620L	620L-OD-041	N/A
		622L	622L-OD-041	N/A
		620H	620L-OD-041	N/A
		622H	622L-OD-041	N/A
	BS	620L	N/A	GT11BS-205
		622L	N/A	GT11BS-205
		620H	N/A	GT11BS-205
		622H	N/A	GT11BS-205
GT31	OH	620L	620L-041	N/A
		622L	622L-041	N/A
		620H	620H-041	N/A
		622H	622H-041	N/A
		624H/626H	Standard	N/A
	OD	620L	620L-OD-041	N/A
		622L	622L-OD-041	N/A
		620H	620L-OD-041	N/A
		622H	622L-OD-041	N/A
		624H/626H	624-OD-041-1-L, 624-OD-041-1-R	N/A
	BS	620L	N/A	GT11BS-205
		622L	N/A	GT11BS-205
		620H	N/A	GT11BS-205
		622H	N/A	GT11BS-205
		624H/626H	N/A	GT31BS-205

Figure 4-18: Rope Gripper® - Machine duty table

4.6.1 Overhead Machine Rope Gripper Mounting

**NOTE -**

CONSULT THE PROPER ROPE GRIPPER INSTALLATION MANUAL FOR INSTALLATION OF THE ROPE GRIPPER.

- Remove the standard mounting feet that come with the rope gripper.
- Attach the non-standard specified in Figure 4-18 to the rope gripper with the required hardware and properly torque.
- Verify the assembly will not interfere with elevator equipment (machine frame, traction or deflector sheave, machine beams, etc.) or any other obstructions.
- Follow the rope gripper manual installation procedure and when appropriate attach the mounting angles to the machine base.
- See Figure 4-19 for an illustration of a finished installation.




Figure 4-19: OH machine with gripper

4.6.2 Basement Set Machine Rope Gripper Mounting

**NOTE -**

CONSULT THE PROPER ROPE GRIPPER INSTALLATION MANUAL FOR INSTALLATION OF THE ROPE GRIPPER.

- If not already completed attach the rope gripper brackets specified in Figure 4-18 to the machine stands with the required hardware and properly torque.
- Verify the assembly will not interfere with elevator equipment (machine frame, traction or deflector sheave, machine beams, etc.) or any other obstructions.
- Follow the rope gripper manual installation procedure and when appropriate attach the mounting angles to the mounting brackets.
- See Figure 4-20 for an illustration of a finished installation.




Figure 4-20: BS Machine with mounted gripper

4.6.3 Overhead Deflector Machine Rope Gripper Mounting

**NOTE -**

CONSULT THE PROPER ROPE GRIPPER INSTALLATION MANUAL FOR INSTALLATION OF THE ROPE GRIPPER.

- Remove the standard mounting feet that come with the rope gripper.
- Attach the non-standard specified in Figure 4-18 to the rope gripper with the required hardware and properly torque.
- Verify the assembly will not interfere with elevator equipment (machine frame, traction or deflector sheave, machine beams, etc.) or any other obstructions.
- Follow the rope gripper manual installation procedure and when appropriate attach the mounting angles to the machine up-stand.
- See Figure 4-21 for an illustration of a finished installation.




Figure 4-21: OD Machine with Mounted Gripper

Section

5

5 Adjustments

WARNING

Always wear the proper PPE when working on any equipment. Please follow your organizations PPE policy when working on Hollister-Whitney equipment.

5.1 Brake Torque Adjustment

The brake torque is set at the factory. No adjustment should be required unless service or maintenance is required on the brake.

5.1.1 Required Tools

Please see Bulletin #1187-1 for tool requirements

5.1.2 Brake Torque Adjustment Procedure

See Bulletin 1187-1 (Service Manual) Section 3.2 for Instruction

5.2 Brake Shoe Gap Adjustment

The brake shoe gap is set at the factory. No adjustment should be required unless service or maintenance is required on the brake.

5.2.1 Required Tools

Please see Bulletin #1187-1 for tool requirements

5.2.2 Brake Shoe Gap Adjustment Procedure

See Bulletin 1187-1 (Service Manual) Section 3.3 for Instruction

5.3 Brake Switch Adjustment

The brake switch actuation is set at the factory. No adjustment should be required unless service or maintenance is required on the brake.

5.3.1 Required Tools

5/8" Open Ended Wrench, 1" Open Ended Wrench, Tamper Resistant Paint

5.3.2 Brake Switch Adjustment Procedure

With the solenoid de-energized and the brakes fully engaged, adjust the adjustment bolt until the switch makes an audible “click” and then rotate the bolt one flat further. Tighten the jam nut once adjusted and apply tamper resistant paint across the nut and adjustment bolt threads.




Figure 5-1: Brake Switch/Adjustment Bolt

5.4 Brake Solenoid Plunger/Adjustment Bolt Gap Adjustment

The brake solenoid plunger/adjustment bolt gap is set at the factory. No adjustment should be required unless service or maintenance is required on the brake.

5.4.1 Required Tools

5/8" Open Ended Wrench, 1" Open Ended Wrench, Tamper Resistant Paint, Measuring Device

5.4.2 Adjustment Procedure

With the solenoid de-energized and the brakes fully engaged, adjust the adjustment bolt until there is axial “free play” of 0.02” minimum between the adjustment bolt and the solenoid plunger. Tighten the jam nut once adjusted and apply tamper resistant paint across the nut and the adjustment bolt threads.




Figure 5-2: Adjustment Bolt/Plunger Gap

5.5 Worm/Gear Backlash Adjustment

The worm/gear backlash is set at the factory. No adjustment should be required unless service or maintenance is required on the worm or gear.

5.5.1 Worm/Gear Backlash End Play

If worm/gear end play adjustment is necessary, then the recommended endplay setting is 0.000" to 0.001".

5.5.2 Required Tools

Please see Bulletin #1187-1 for tool requirements

5.5.3 Worm/Gear Backlash Adjustment Procedure

The worm/gear backlash adjustment procedure can be found in Bulletin #1187-1 (Service Manual) Section 5.5. Due to the complexity of adjusting the backlash, please go to the Hollister-Whitney Channel on YouTube for instructions. Scan the following QR code for direct access to the video:



5.6 Worm/Gear Pattern Adjustment

The worm/gear pattern is set at the factory. No adjustment should be required unless service or maintenance is required on the worm or gear.

5.6.1 Required Tools

Please see Bulletin #1187-1 for tool requirements

5.6.2 Worm/Gear Recommended Pattern

If the worm/gear pattern adjustment is necessary, then the recommended pattern for a GT-series machine is a centered pattern. The centered pattern should be on both flanks and should look similar to Figure 5-3 when adjusted per the recommendation:




Figure 5-3: Centered Worm/Gear Pattern

5.6.3 Worm/Gear Pattern Adjustment Procedure

The worm/gear pattern adjustment procedure can be found in Bulletin #1187-1 (Service Manual). However, due to the complexity of adjusting the worm/gear pattern, please go to the Hollister-Whitney Channel on YouTube for instructions. Scan the following QR code for direct access to the video:



Section

6

6 Maintenance

WARNING

Before performing any maintenance checks on equipment, take all the necessary safety precautions to immobilize the car and counterweight to prevent any unintended movement during the maintenance period that may result in injury or death!

6.1 General

To keep equipment functioning efficiently, good maintenance practices must be established, observed, and maintained. Systematic inspections of the equipment should be scheduled, and records kept of these inspections. Monitoring these records will indicate any sign of a potential issue.

Each installation has its own special considerations, as a result it is difficult for Hollister-Whitney to outline specific plans for periodic inspections and maintenance. However, Section 6.3 provides a general recommendation inspection and maintenance table. However, the maintenance contractor will need to make the final determination.

All ASME A17.1 code required inspections, maintenance, and periodic tests shall be followed.


6.2 Cleaning

Dirt, dust, excess lubrication, and moisture are the greatest enemies of electrical equipment and of maintenance teams in general. Dirt and dust layers on a machine can prevent heat dissipation, which can lead to overheating. Dust and dirt can draw moisture to unpainted surfaces such as brake components causing oxidation that can cause brake faults. Excess lubrication can draw dust and dirt as well.

Dust and dirt can be removed from surfaces with a dry, lint-free cloth, or with suction. With suction, however, care must be taken to not build up or discharge static electricity while cleaning. Dry, compressed air (at less than 50psi) may also be used to remove dirt and dust, however, this must be closely monitored as the compressed air will re-suspend the dust and dirt in the machine room atmosphere.

6.3 Recommended Inspection / Maintenance

6.3.1 Lubrication System

Type	Item	Interval	Requirement
Maintenance	Oil Change	<u>Initial Interval:</u> 400 hrs after installation <u>Ongoing Interval:</u> Every 2,500 hrs of machine runtime	Use Mobil SHC 636 gear box oil See Bulletin #1187-1 (Service Manual) for oil change instructions
Inspection	Oil Level	Monthly	Oil level must be between 1/8" of top and 1/8" of bottom of oil sight glass window after not running for 15 minutes 
Inspection	Oil Leaks	Monthly	No leaks
Inspection	Oil Quality	Quarterly	1. The oil should have a consistent viscosity with no coagulation 2. The oil should not have a "burnt" or foul odor

6.3.2 Drive System

Type	Item	Interval	Requirement
Inspection	Bronze Gear Tooth Wear	Yearly	Any "grooving" in the bronze gear in the area where the bronze gear meshes with the worm should not exceed a step depth of 1/32"
Inspection	Rope Groove Wear	Quarterly	1. Rope height across all ropes must be within 1/32" of an inch relative to each other. See 6.4.1. for additional information. 2. No evidence of metal "filings" accumulating around the traction wheel

6.3.3 Guarding/Rope Retention



Type	Item	Interval	Requirement
------	------	----------	-------------


Inspection	Guarding	Monthly	Guarding and rope retainers should have enough clearance to prevent any rubbing
------------	----------	---------	---

6.3.4 Brake System

⚠ WARNING

If the brake pad wears too much, the brake will be not function properly.

Type	Item	Interval	Requirement
Inspection	Brake Pad to Brake Drum Clearance When Pads Disengaged from Drum	Monthly	<p>Gap must be .002" to .007"</p>  <p>If out of adjustment, follow adjustment procedure detailed in Section 5</p>
Inspection	Brake Pad Thickness	Quarterly	<p>Minimum of .125" (1/8") pad thickness</p>  <p>If less than 1/8" material is present, replace the brake shoe</p>
Inspection	Brake Adjustment Seal	Monthly	Tamper evident paint seal must not be cracked



6.4 Other Items / Comments

6.4.1 Traction Wheels

Traction wheels are the most likely item to wear. Periodic measurements of rope depth and the evenness of wear for all ropes (groove depth should wear evenly) should be monitored. Cable should not be more than 0.125 inch (1/8") below the outer rim of the traction wheel. If cables, are below 0.125 inch, or if wear is uneven, replace the traction wheel and cables.

DO NOT re-groove sheaves.

6.4.2 Bearings

Bearings have been sized for the maximum speeds, loads and capacities found in this manual. Bearings are sealed and require no maintainable lubrication.

Section

7

7 Service / Replacement


For service and replacement instructions please refer to Bulletin #1187-1 (Service Manual)

Please go to the Hollister-Whitney YouTube Channel for video instructions on many service procedures detailed in the service manual. Scan the following QR code for direct access to the video:




7.1 General Assembly Drawings

7.1.1 GT310H





ENGINEERING MASTER PARTS LIST		
ITEM	QTY	PART NUMBER DESCRIPTION
1	1	GT31-273-01 ASSY. GEAR BOX, SINGLE LEAD, 71:1
		GT31-273-02 ASSY. GEAR BOX, DOUBLE LEAD, 71:2
		GT31-273-03 ASSY. GEAR BOX, TRIPLE LEAD, 71:3
2	1	GT31-0H-1 ASSY. BASE, FINISHED
3	1	GT31-005 STAND, OUTBOARD
4	AS REQ'D	GT31-082-05 SHIM, STAND, OUTBOARD, 0.0050" THICK
		GT31-082-10 SHIM, STAND, OUTBOARD, 0.0100" THICK
		GT31-082-31 SHIM, STAND, OUTBOARD, 0.0310" THICK
5	1	GT31-093 BEARING, ROLLER, SPHERICAL
6	1	GT31-250-26 ASSY. RETAINER, ROPE, 26"
7	1	GT31-250-30 ASSY. RETAINER, ROPE, 30"
8	1	GT31-281 COVER, STAND, OUTBOARD
9	1	GT31-283 NUT, LOCK, SHAFT
10	1	GT31-286-26 ASSY. TRACTION WHEEL AND HUB, 26"
11	2	GT31-290 CONDUIT, METAL, FLEXIBLE, 3/8"
12	2	GT31-291 ADAPTER, STRAIGHT, FMC, 3/8"
13	2	GT31-293 ADAPTER, FMC, 90 DEG ELBOW, 3/8"
14	1	GT31-297-1-625 COUPLER, MOTOR, 1.625" / 254TC / 254TC FRAME
		GT31-297-1-875 COUPLER, MOTOR, 1.875" / 254TC / 254TC FRAME
		GT31-297-2-125 COUPLER, MOTOR, 2.125" / 324TC / 324TC FRAME
		GT31-297-2-375 COUPLER, MOTOR, 2.375" / 364TC / 365TC FRAME
15	1	GT31-298 ELEMENT, COUPLING
16	2	GT31-299 BUSHING, ANTI-SHORT, FEMALE, FMC, 3/8"
17	1	GT31-300 KEY, SHAFT, WHEEL
18	1	GT31-310 NUT, LOCK, SHAFT
19	1	GT31-311 WASHER, LOCK, SHAFT
20	1	GT31-312 PLATE, ADAPTER, MOTOR, 254TC / 254TC / 254TC FRAME
21	1	GT31-314 PLATE, ADAPTER, MOTOR, 324TC / 324TC / 364TC FRAME
22	2	GT31-315 ASSY. SOLENOID, BRAKE
23	2	GT31-321 PIN, PIVOT
24	1	GT31-322 DRUM, BRAKE
25	1	GT31-326 PLATE, RETENTION, BEARING, STAND
26	2	GT31-327 ASSY. SWITCH, BRAKE
27	1	GT31-356 ASSY. BLOCK, TERMINAL
28	1	P-208 MANUAL, BRAKE RELEASE TAG
29	2	P-223-R CUSTOMER NAMEPLATE
30	1	P-226 LABEL, DATA, ELECTRICAL, BRAKE
31	1	P-227 LABEL, INSTRUCTION, BRAKE
32	1	P-228 TAG, DATA, MOTOR, CONTRACT
33	1	P-231 TAG, DATA, MOTOR, CONTRACT
34	1	P-236 MACHINE DATA TAG
35	4	#6-32 UNC X 7/8" SCREW, HEX HEAD
36	4	5/16-18 UNC X 3/4" BOLT, HEX, SERRATED FLANGE, GRADE 5, ZINC-PLATED
37	1	7/16-14 UNC X 3/4" SCREW, HEX, CAP, SOCKET HEAD, BLACK OXIDE FINISH
38	AS REQ'D	1/2-13 UNC X 1-1/2" BOLT, HEX, SERRATED FLANGE, GRADE 5, ZINC-PLATED
39	AS REQ'D	1/2-13 UNC X 1-1/2" SCREW, HEX, CAP, FLAT SOCKET HEAD, BLACK OXIDE FINISH
40	4	5/8" - MS 16824 RING, RETAINING, EXTERNAL, SERIES 3100
41	4	5/8" X 1-1/2" PIN, DOWEL, GROUND, HARDENED
42	AS REQ'D	5/8" - 11 UNC X 1-1/2" BOLT, HEX, SERRATED FLANGE, GRADE 5, ZINC-PLATED
43	8	3/4"-10 UNC X 2-1/2" BOLT, HEX, GRADE 5, BLACK OXIDE FINISH
44	8	3/4" WASHER, LOCK, HELICAL
45	2.5 gal	MOBIL SHC 688 OIL, GEAR, HIGH PRESSURE

GT31-273 PARTS LIST				
ITEM	QTY	QTY	QTY	PART NUMBER DESCRIPTION
GT31-273-01	1	0	0	GT31-080-01 ASSY. CENTER, SINGLE LEAD
2.1	1	0	0	GT31-080-02 ASSY. CENTER, DOUBLE LEAD
2.1	0	1	0	GT31-080-03 ASSY. CENTER, TRIPLE LEAD
2.1	0	0	1	GT31-294 ASSY. UPPER AND LOWER HOUSING, MACHINED
2.2	1	0	0	GT31-294-01 ASSY. WORN SHAFT AND BEARING, 7/8" SINGLE
2.3	1	0	0	GT31-294-02 ASSY. WORN SHAFT AND BEARING, 7/8" DOUBLE
2.3	0	0	1	GT31-294-03 ASSY. WORN SHAFT AND BEARING, 7/8" TRIPLE
2.3	0	0	1	GT31-183 CAP, FILL, OIL
2.4	1	1	1	GT31-085 CAP, BEARING, REAR END
2.5	1	1	1	GT31-085 CAP, BEARING, FORWARD END
2.6	1	1	1	GT31-087 GLASS, SIGHT, OIL
2.7	7	1	1	GT31-276 PLUG, DRAIN, OIL
2.8	1	1	1	GT31-277 O-RING, PLUG, OIL
2.9	1	1	1	GT31-278 SEAL, SHAFT, RADIAL
2.10	1	1	1	GT31-279 SEAL, SHAFT, RADIAL
2.11	1	1	1	GT31-281 SHIM, ECCENTRIC, EDGE BONDED
2.12	1	1	1	GT31-301 KEY, SHAFT, WORN
2.13	4	4	4	1/2-13 UNC X 1.5 BOLT, HEX, SERRATED FLANGE, GRADE 5, ZINC-PLATED
2.14	1	1	1	
2.15	1	1	1	
2.16	20	20	20	




B		CORRECTED COPY		DRO		A		COMBINED ALL WHEEL SIZES TO ONE PRINT. UPDATED PARTS LIST TO MOTOR PRINTS. P/R #1754		DRO 05/08/23		HOLLISTER-WHITNEY ELEVATOR CO., LLC	
B		TABLES, P/R #1772		05/18/23								ASSY. GT31, LEFT HAND	
												REFERENCE TO ALL DIMENSIONS IN PARENTHESES	
												GT31-LH	
												SHEET 2	






7.1.2 GT31BS





ENGINEERING MASTER PARTS LIST		
ITEM	QTY	PART NUMBER
1	1	GT31BS-273-01
2	1	GT31BS-273-02
3	1	GT31BS-273-03
4	1	GT31BS-001
5	1	GT31BS-005
6	1	GT31BS-006
7	1	GT31BS-007
8	1	GT31BS-008
9	1	GT31BS-009
10	1	GT31BS-010
11	1	GT31BS-011
12	1	GT31BS-012
13	1	GT31BS-013
14	1	GT31BS-014
15	1	GT31BS-015
16	1	GT31BS-016
17	1	GT31BS-017
18	1	GT31BS-018
19	1	GT31BS-019
20	1	GT31BS-020
21	1	GT31BS-021
22	1	GT31BS-022
23	1	GT31BS-023
24	1	GT31BS-024
25	1	GT31BS-025
26	1	GT31BS-026
27	1	GT31BS-027
28	1	GT31BS-028
29	1	GT31BS-029
30	1	GT31BS-030
31	1	GT31BS-031
32	1	GT31BS-032
33	1	GT31BS-033
34	1	GT31BS-034
35	1	GT31BS-035
36	1	GT31BS-036
37	1	GT31BS-037
38	1	GT31BS-038
39	1	GT31BS-039
40	1	GT31BS-040
41	1	GT31BS-041
42	1	GT31BS-042
43	1	GT31BS-043
44	1	GT31BS-044
45	1	GT31BS-045
46	1	GT31BS-046




GT31BS-273 PARTS LIST		
ITEM	QTY	PART NUMBER
1	1	GT31BS-273-01
2	1	GT31BS-273-02
3	1	GT31BS-273-03
4	1	GT31BS-001
5	1	GT31BS-005
6	1	GT31BS-006
7	1	GT31BS-007
8	1	GT31BS-008
9	1	GT31BS-009
10	1	GT31BS-010
11	1	GT31BS-011
12	1	GT31BS-012
13	1	GT31BS-013
14	1	GT31BS-014
15	1	GT31BS-015
16	1	GT31BS-016
17	1	GT31BS-017
18	1	GT31BS-018
19	1	GT31BS-019
20	1	GT31BS-020
21	1	GT31BS-021
22	1	GT31BS-022
23	1	GT31BS-023
24	1	GT31BS-024
25	1	GT31BS-025
26	1	GT31BS-026
27	1	GT31BS-027
28	1	GT31BS-028
29	1	GT31BS-029
30	1	GT31BS-030
31	1	GT31BS-031
32	1	GT31BS-032
33	1	GT31BS-033
34	1	GT31BS-034
35	1	GT31BS-035
36	1	GT31BS-036
37	1	GT31BS-037
38	1	GT31BS-038
39	1	GT31BS-039
40	1	GT31BS-040
41	1	GT31BS-041
42	1	GT31BS-042
43	1	GT31BS-043
44	1	GT31BS-044
45	1	GT31BS-045
46	1	GT31BS-046


CORRECTED COPY		DNO		A		COMBINED ALL WHEEL SIZES TO ONE PRINT. UPDATED PARTS LIST. TO MOTOR PRINTS. PUR 81754		DNO		HOLLISTER-WHITNEY ELEVATOR CO. LLC	
B		TABLES, PUR 81772		05/18/23		THIRD ANGLE PROJECTION		DNO		ASSY, GT31, LEFT HAND, BS	
C		5/8/2023		DATE		BY		DNO		REFERENCE TO: ALL DIMENSIONS UNLESS OTHERWISE SPECIFIED	
3		SHEET		C		5/8/2023		GT31BS-LH		SHEET 3	







7.1.3 GT310D













7.1.4 GT110H




G111-223 PARTS LIST				
ITEM	QTY	QTY	QTY	PART NUMBER DESCRIPTION
2.1	1	0	0	G111-1000-01 ASSY. CENTER SINGLE LEAD
2.1	0	1	0	G111-1000-02 ASSY. CENTER DOUBLE LEAD
2.1	0	0	1	G111-1000-03 ASSY. CENTER TRIPLE LEAD
2.2	1	1	1	G111-1294 ASSY. UPPER AND LOWER HOUSING, MACHINED
2.3	1	0	0	G111-1294-01 ASSY. WORM SHAFT AND BEARING, 1/8" SINGLE
2.3	0	1	0	G111-1294-02 ASSY. WORM SHAFT AND BEARING, 7/8" DOUBLE
2.3	0	0	1	G111-1294-03 ASSY. WORM SHAFT AND BEARING, 7/8" TRIPLE
2.5	2	2	2	G111-1367 CAP. FILL OIL
2.5	1	1	1	G131-063 BOLT, HOUSING, GUARD MOUNTING
2.6	1	1	1	G131-065 CAP. BEARING, REAR END
2.6	1	1	1	G131-065 FE CAP. BEARING, FORWARD END
2.7	1	1	1	G131-087 SHIM, CAP BEARING
2.8	AS RECD	AS RECD	AS RECD	G131-087 GLASS, SIGHT OIL
2.9	1	1	1	G131-276 PUG, DRAIN OIL
2.10	1	1	1	G131-277 PUG, OIL
2.11	1	1	1	G131-278 PUG, OIL
2.12	1	1	1	G131-279 O-RING, PUG OIL
2.13	1	1	1	G131-287 SEAL, SHAFT, RADIAL
2.14	1	1	1	G131-287-1 SEAL, SHAFT, RADIAL
2.15	4	4	4	G131-295 SHIM, ECCENTRIC EDGE BONDED
2.16	1	1	1	G131-301 KEY, SHAFT, WORM
2.17	20	20	20	1/2-13 UNC X 1-5 BOLT, HEX, SERRATED FLANGE, GRADE 5, ZINC-PLATED








7.1.5 GT11BS





NOTES UNLESS OTHERWISE SPECIFIED:
1. FOUNDATION/ANCHORING SHALL BE DESIGNED BY OTHERS ON THE ABOVE SPECIFICATIONS. HOLLISTER-WHITNEY ASSUMES NO RESPONSIBILITY FOR THE DESIGN OF THE FOUNDATION.

FOUNDATION BOLT REACTION FORCES			
LOCATION	REACTION TYPE	TO DETERMINE THE LOCATION REACTION FORCE MULTIPLY THE SHEAVE SHAFT LOAD BY THE FOLLOWING % (- SIGN INDICATES FORCE DIRECTION)	TO DETERMINE PSI OF COMPRESSIVE LOAD DIVIDE THE COMPRESSIVE FORCE BY THE FOLLOWING
"A"	COMPRESSION	-10.6%	12.6 in²
"B"	TENSION	12.7%	N/A
"C"	TENSION	12.7%	N/A
"D"	TENSION	42.6%	N/A
"E"	TENSION	42.6%	N/A

THIS DRAWING IS SUPPLIED AS A REPRESENTATION OF THE EQUIPMENT. HOLLISTER-WHITNEY ELEVATOR CO., LLC. DISCLAIMS ANY LIABILITY FOR THE EQUIPMENT'S PERFORMANCE, SAFETY, OR RELIABILITY. ANY MODIFICATIONS NOT APPROVED IN WRITING BY HOLLISTER-WHITNEY ELEVATOR CO., LLC. SHALL BE AT THE USER'S SOLE RISK. HOLLISTER-WHITNEY ELEVATOR CO., LLC. RELEASES ALL LIABILITY FOR ANY DAMAGE, LOSS, OR INJURY, INCLUDING CONSEQUENTIAL AND INCIDENTAL DAMAGES, ARISING FROM THE USE OF THIS EQUIPMENT. HOLLISTER-WHITNEY ELEVATOR CO., LLC. WRITING AUTHORIZATION FROM THE MANUFACTURER.

COMBINED ALL WHEEL SIZES TO ONE PRINT. UPDATED MOTOR DATA TO MOTOR PRINTS. PUR #1764

DRO 05/08/23

THIRD ANGLE PROJECTION

HOLLISTER-WHITNEY ELEVATOR CO., LLC

ASSY, GT11BS, LEFT HAND


DRAWN BY: SCALE MATERIAL: DATE: 4/25/2023


DRO 1:12 SEE PARTS LIST


SHEET SIZE B


REFERENCE TOL. ALL UNLESS OTHERWISE SPECIFIED

GT11BS-LH SHEET 2


[illegible]

THIS DRAWING IS THE PROPERTY OF THE DRAWING OFFICE AND IS LOANED TO THE CLIENT. IT IS TO BE USED FOR THE PROJECT SPECIFICALLY IDENTIFIED HEREON. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM. ANY UNAUTHORIZED REPRODUCTION OR USE OF THIS DRAWING IS STRICTLY PROHIBITED. THE DRAWING OFFICE ASSUMES NO LIABILITY FOR ANY ERRORS OR OMISSIONS. THE CLIENT AGREES TO HOLD THE DRAWING OFFICE HARMLESS FROM ANY AND ALL CLAIMS, DAMAGES, LOSSES, AND EXPENSES, INCLUDING ATTORNEY'S FEES, ARISING OUT OF OR RESULTING FROM THE USE OF THIS DRAWING.		COMBINED ALL WHEEL SIZES TO ONE PRINT UNLOCATED PARTS LIST UNLOCATED PARTS LIST TO MOTOR PRINTS	DRG 05/08/23	TITLE	ASSY GT11BS, LEFT HAND
THIRD ANGLE PROJECTION 		DRAWING SCALE: PARTIAL BY DRG 1:10 SEE PARTS LIST DATE 4/26/2023			
REFERENCE TOOL ALL DIMENSIONS IN INCHES UNLESS OTHERWISE SPECIFIED		GT11BS-LH SHEET 1			






7.1.6 GT110D




ENGINEERING MASTER PARTS LIST		
ITEM	QTY	PART NUMBER DESCRIPTION
1	1	GT11BS-273-01 ASSY. GEAR BOX, SINGLE LEAD, 49-1
		GT11BS-273-02 ASSY. GEAR BOX, DOUBLE LEAD, 49-2
		GT11BS-273-03 ASSY. GEAR BOX, TRIPLE LEAD, 49-3
2	1	GT11BS-001 BASE, BS-OD
3	1	GT11BS-005 STAND, OUTBOARD, BS
4	1	GT11BS-006 STAND, INBOARD, BS
5	1	GT11-093 BEARING, ROLLER, SPHERICAL
6	1	GT11OD-250-22 ASSY. RETAINER, ROPE, OD, 22"
		GT11OD-250-26 ASSY. RETAINER, ROPE, OD, 26"
		GT11OD-250-30 ASSY. RETAINER, ROPE, OD, 30"
7	1	GT11OD-331-027R ASSY. SLEEVE, BALL BEARING, SEALED
		GT11OD-331-027SR ASSY. SLEEVE, SPHERICAL ROLLER BEARING, SEALED
8	1	GT11-282 NUT, LOCK, SHAF
9	1	GT11-283 WASHER, LOCK, SHAF
10	1	GT11-286-22 ASSY. TRACTION WHEEL, AND HUB, 22"
		GT11-286-26 ASSY. TRACTION WHEEL, AND HUB, 26"
		GT11-286-30 ASSY. TRACTION WHEEL, AND HUB, 30"
11	2	GT11-315 ASSY. ARM, BRAKE
12	1	GT11-326 PLATE, RETENTION, BEARING, STAND
13	1	GT11BS-368 RETAINING RING, SPIRAL, MEDIUM DUTY
14	2	GT11OD-005 SHIM, STAND, OUTBOARD, OD
		GT11OD-005 SHIM, STAND, OUTBOARD, OD
15	AS REQD	GT11-082-05 SHIM, STAND, OUTBOARD, 0.0105" THK
		GT11-082-10 SHIM, STAND, OUTBOARD, 0.0107" THK
		GT11-082-31 SHIM, STAND, OUTBOARD, 0.0310" THK
16	1	GT11-093 BEARING, ROLLER, SPHERICAL
17	2	GT11OD-144 SPACER, STAND, OD
18	3	GT11-291 ADAPTER, FMC, 90 DEG ELBOW, 3/8"
19	2	GT11-291 ADAPTER, STRAIGHT, FMC, 3/8"
20	2	GT11-291 COUPLER, MOTOR, 1.625", 254TC / 256TC FRAME
21	1	GT11-297-1.625 COUPLER, MOTOR, 1.875", 284TC / 286TC FRAME
		GT11-297-1.875 COUPLER, MOTOR, 2.125", 324TC / 326TC FRAME
		GT11-297-2.125 COUPLER, MOTOR, 2.375", 364TC / 366TC FRAME
22	1	GT11-298 ELEMENT, COUPLING
23	2	GT11-299 BUSHING, ANT-SHORT, FEMALE, FMC, 3/8"
24	1	GT11-300 KEY, SHAFT, WHEEL
25	1	GT11-310 NUT, LOCK, SHAF
26	1	GT11-311 WASHER, LOCK, SHAF
27	1	GT11-312 PLATE, ADAPTER, MOTOR, 254TC / 256TC / 284TC / 286TC FRAME
		GT11-313 PLATE, ADAPTER, MOTOR, 324TC / 326TC / 364TC / 366TC FRAME
28	1	GT11-314 ASSY. SOLENOID, BRAKE
29	2	GT11-321 PIN, PIVOT
30	1	GT11-322 DRUM, BRAKE
31	2	GT11-327 ASSY. SWITCH, BRAKE
32	2	GT11OD-335 COLUMN, SUPPORT, ADJUSTABLE
33	1	GT11-358 ASSY. BLOCK, TERMINAL
34	1	P-208 MANUAL BRAKE RELEASE TAG
35	1	P-226 LABEL, DATA, ELECTRICAL, BRAKE
36	1	P-227 LABEL, INSTRUCTION, BRAKE
37	1	P-228 LABEL, WIRING, BRAKE
38	1	P-230 NAMEPLATE, SMALL, HOLLISTER-WHITNEY
39	1	P-231 TAG, DATA, MOTOR, CONTRACT
40	1	P-236 MACHINE, HEX HEAD
41	4	#8 - 32 UNC x 7/8" SCREW, HEX HEAD
42	1	5/16" - 18 UNC x 3/4" BOLT, HEX, SERATED FLANGE, GRADE 5, ZINC-PLATED
43	1	7/16" - 14 UNC x 2-1/4" SCREW, HEX, CAP, SOCKET HEAD, BLACK OXIDE FINISH
44	AS REQD	1/2" - 13 UNC x 1-1/2" BOLT, HEX, SERATED FLANGE, GRADE 5, ZINC-PLATED
45	AS REQD	1/2" - 13 UNC x 1-1/2" SCREW, HEX, CAP, FLAT SOCKET HEAD, BLACK OXIDE FINISH
46	4	5/8" - MS 16824 RING, RETAINING, EXTERNAL, SERIES 3100
47	6	5/8" x 1-1/2" PIN, DOWEL, GROUND, HARDENED
48	6	5/8" LOCK WASHER, HELICAL SPRING, REGULAR
49	AS REQD	5/8" - 11 UNC x 1-1/2" BOLT, HEX, SERATED FLANGE, GRADE 5, ZINC-PLATED
50	6	5/8" - 11 UNC x 3" HEX CAP SCREW
51	28	3/4" - 10 UNC x 2-1/2" LOCK WASHER, HELICAL SPRING, REGULAR
52	12	3/4" - 10 UNC x 3" HEX CAP SCREW, GRADE 5, BLACK OXIDE FINISH
53	16	3/4" - 10 UNC x 3" HEX CAP SCREW, GRADE 5, BLACK OXIDE FINISH
54	1,75 gal	MOBIL SHC 636 OIL, GEAR, HIGH PRESSURE

GT11-273 PARTS LIST		
ITEM	QTY	PART NUMBER DESCRIPTION
2.1	1	GT11BS-273-01 ASSY. CENTER, BS-OD, SINGLE LEAD
2.1	0	GT11BS-080-01 ASSY. CENTER, BS-OD, DOUBLE LEAD
2.1	0	GT11BS-080-02 ASSY. CENTER, BS-OD, TRIPLE LEAD
2.1	0	GT11BS-080-03 ASSY. CENTER, BS-OD, TRIPLE LEAD
2.2	1	GT11-284 ASSY. UPPER AND LOWER HOUSING, MACHINED
2.3	0	GT11-284-01 ASSY. WORM SHAFT AND BEARING, 7/8" SINGLE
2.3	0	GT11-284-02 ASSY. WORM SHAFT AND BEARING, 7/8" DOUBLE
2.3	0	GT11-284-03 ASSY. WORM SHAFT AND BEARING, 7/8" TRIPLE
2.4	1	GT11-083 CAP, FILL, OIL
2.5	1	GT11-085 CAP, BEARING, REAR END
2.6	1	GT11-085-FE SHIM, CAP, BEARING
2.7	AS REQD	GT11-087 GLASS, SIGHT, OIL
2.8	1	GT11-276 PLUG, DRAIN, OIL
2.9	1	GT11-277 PLUG, OIL
2.10	1	GT11-278 O-RING, PLUG, OIL
2.11	1	GT11-279 SEAL, SHAF, RADIAL
2.12	1	GT11-287 SEAL, SHAF, RADIAL
2.13	1	GT11-297-1 SHIM, ECCENTRIC, EDGE BONDED
2.14	4	GT11-295 KEY, SHAF, WORM
2.15	1	GT11-301 BOLT, HEX, SERATED FLANGE, GRADE 5, ZINC-PLATED
2.16	20	1/2" - 13 UNC x 1.5"





GT11OD-LH
SCALE 1:12



GT11BS-273
SCALE 1:12

HOLLISTER-WHITNEY ELEVATOR CO. LLC	
DRAWN: SCALE: 1:12 CHECKED: 4/25/2023 DATE: 4/25/2023	THIRD ANGLE PROJECTION DRO 1:12 SEE PARTS LIST REFERENCE TO: GT11OD-LH












7.2 Assembly Replacement Kits






KIT NUMBER	DESCRIPTION
GT31-188	BEARING & SEAL ASSEMBLY - COMPLETE MACHINE
GT31-188-1	BEARING & SEAL ASSEMBLY - COMPLETE MACHINE: INCLUDES BEARINGS & GEAR HUB PRE-ASSEMBLED TO MAIN SHAFT
GT31-189	BEARING & SEAL ASSEMBLY - MAIN SHAFT
GT31-189-1	BEARING & SEAL ASSEMBLY - MAIN SHAFT: INCLUDES BEARINGS & GEAR HUB PRE-ASSEMBLED TO MAIN SHAFT
GT31-190	SEAL & GASKET ASSEMBLY - COMPLETE MACHINE
GT31-202	BEARING & SEAL ASSEMBLY - WORM SHAFT
GT31-WG	BEARING & SEAL ASSEMBLY - WORM SHAFT: INCLUDES WORM & GEAR REPLACEMENT SET
GT11-188	BEARING & SEAL ASSEMBLY - COMPLETE MACHINE
GT11-188-1	BEARING & SEAL ASSEMBLY - COMPLETE MACHINE: INCLUDES BEARINGS & GEAR HUB PRE-ASSEMBLED TO MAIN SHAFT
GT11-189	BEARING & SEAL ASSEMBLY - MAIN SHAFT
GT11-189-1	BEARING & SEAL ASSEMBLY - MAIN SHAFT: INCLUDES BEARINGS & GEAR HUB PRE-ASSEMBLED TO MAIN SHAFT
GT11-190	SEAL & GASKET ASSEMBLY - COMPLETE MACHINE
GT11-202	BEARING & SEAL ASSEMBLY - WORM SHAFT
GT11-WG	BEARING & SEAL ASSEMBLY - WORM SHAFT: INCLUDES WORM & GEAR REPLACEMENT SET

*Contact Hollister-Whitney sales for guidance on the appropriate assembly replacement kit


7.3 Individual Component Replacement Parts

Machine Model	Part Number	QTY Per Machine	Description	Image
All	GT31-314 (190V version) GT31-314-1 (110V version)	1	Solenoid, Brake	
All	GT31-314-002A	1	Assy, Replacement, Handle, Brake	
All	GT31-314-003A	1	Assy, Replacement, Cover, Solenoid	
All	GT31-316	2	Assy, Shoe and Pad, Brake	
All	GT31-324	2	Spring, Brake	
All	GT31-327	2	Assy, Switch, Brake	

Machine Model	Part Number	QTY Per Machine	Description	Image
All	GT31-358	1	Assy, Block, Terminal	
All	GT31-297-1.625 GT31-297-1.875 GT31-297-2.125 GT31-297-2.375	1	Coupler, Motor (based on motor shaft dia.)	
All	GT31-322	1	Drum, Brake	
All	GT31-298	1	Element, Coupling	
All	GT31-276	1	Glass, Sight, Oil	
All	GT31-277	1	Plug, Drain, Oil	
All	GT31-278	1	Plug, Oil	
All	GT31-063	1	Cap, Fill, Oil	


Machine Model	Part Number	QTY Per Machine	Description	Image
All	GT31-287	1	Seal, Shaft, Radial, Inner	
All	GT31-287-1	1	Seal, Shaft, Radial, Outer	
All	GT31-087	Varies	Shim/Seal, Cap, Bearing	
All	GT31-090	2	Bearing, Roller, Tapered (used on all worms)	
All	GT31-062-05 GT31-062-10 GT31-062-31	Varies	Shim, Stand, Outboard (thicknesses = 0.005", 0.010", and 0.031")	
All	GT31-310	1	Nut, Lock, Shaft (KM10 - used on all worms)	
All	GT31-311	1	Washer, Lock, Shaft (MB10 - used on all worms)	
All	GT31-300	2	Key, Shaft, Shaft, Drive	

Machine Model	Part Number	QTY Per Machine	Description	Image
All	GT31-301	1	Key, Shaft, Worm	
GT31OH GT31BS GT31OD	GT31-093	3	Bearing, Roller, Spherical (used on drive shaft)	
GT31BS GT31OD	GT31-094	1	Bearing, Roller, Spherical (used on drive shaft)	
GT31OH GT31BS GT31OD	GT31-282	2	Washer, Lock, Shaft (KM22 - used on drive shaft)	
GT31OH GT31BS GT31OD	GT31-283	2	Washer, Lock, Shaft (MB22 - used on drive shaft)	
GT11OH GT11BS GT11OD	GT11-093	3	Bearing, Roller, Spherical (used on drive shaft)	
GT11OH GT11BS GT11OD	GT11-282	2	Washer, Lock, Shaft (KM18 - used on drive shaft)	
GT11OH GT11BS GT11OD	GT11-283	2	Washer, Lock, Shaft (MB18 - used on drive shaft)	


Machine Model	Part Number	QTY Per Machine	Description	Image
GT31OH GT31BS GT31OD	GT31-092	1	Seal, Grease (used on drive shaft)	

7.4 Gripper Mounting Equipment Assembly Drawings


7.4.1 620H-041




7.4.2 620L-041




7.4.3 620L-OD-041




7.4.4 622H-041




7.4.5 622L-041




7.4.6 622L-OD-041




7.4.7 624-OD-041



7.4.8 GT11BS-205



7.4.9 GT31BS-205



Section

8

8 Appendix

8.1 Encoder Supplier Data





English:

(Original version)

User's Manual

For UL compliance:

CAUTION**Sensitive products.**

The device could be damaged or be destroyed.
 ▶ Do not use a hammer for adjusting the device.

CAUTION**Electrostatic sensitive devices.**

The device could be damaged or be destroyed.
 ▶ Observe precautions for handling.

Français:

(La version anglaise constitue la version originale.)

Instructions d'utilisation






Pour le respect de la conformité UL:

ATTENTION**Produits fragiles.**

Risque de dommages ou de destruction de l'appareil.
 ▶ Ne pas utiliser de marteau pour le régler.

ATTENTION**Appareil sensible aux décharges électrostatiques.**

Risque de dommages ou de destruction de l'appareil.
 ▶ Prendre les précautions nécessaires pour la manipulation.

**Technical data:**

- This device is intended to determine absolute or differential rotation positions. It is also possible to measure rotation speeds.
- Altitude up to 2000 m [2187.2 yds].
- Overvoltage category I.
- Electrical power input: minimum 5 V DC - maximum 30 V DC \pm as marked, depends on type, fluctuations not exceed $\pm 10\%$ of nominal voltage, class 2.
Please see datasheet on www.kuebler.com or labels on the product for details.
- Signal inputs and outputs: class 2.
- Max relative humidity 93% at 40°C [104°F].
- Pollution degree 2.
- No ventilation required.
- Indoor use, outdoor use possible, not intended for direct exposure to UV-radiation.
- Temperature range minimum -20°C [-4°F] up to +70°C [158°F] (depends on type). Range could be extended.
Please see datasheet on www.kuebler.com for details.
- Cleaning only with water.
- Electrical connections and ratings: see labels on product or in the datasheets on www.kuebler.com.
- Valid accessories you can find in catalogue on www.kuebler.com.
- This device is maintenance-free and need no consumable material.

Données techniques:

- Cet appareil est destiné à la détermination de positions en rotation absolues ou différentielles. Il permet également la mesure de vitesses de rotation.
- Altitude jusqu'à 2000 m [2187.2 yds].
- Catégorie de surtension I.
- Alimentation électrique : minimum 5 V DC - maximum 30 V DC \pm selon indication, en fonction du type, fluctuations maximales $\pm 10\%$ de la tension nominale, classe 2.
Se reporter à la fiche technique à l'adresse Internet www.kuebler.com ou aux étiquettes du produit pour des détails.
- Entrées et sorties de signal : classe 2.
- Humidité relative max. 93% à 40°C [104°F].
- Degré de pollution 2.
- Ne nécessite aucune ventilation.
- Pour utilisation à l'intérieur, utilisation à l'extérieur possible, n'est pas prévu pour une exposition directe au rayonnement UV.
- Plage de températures minimale -20°C [-4°F] à +70°C [158°F] (selon le type). Cette plage pourrait s'élargir.
Se reporter à la fiche technique à l'adresse Internet www.kuebler.com pour des détails.
- Nettoyage à l'eau uniquement.
- Raccordements et valeurs électriques: voir les étiquettes apposées sur le produit ou les fiches techniques à l'adresse Internet www.kuebler.com.
- Vous trouverez les accessoires pour cet appareil dans notre catalogue à l'adresse Internet www.kuebler.com.
- Cet appareil est sans maintenance et ne nécessite aucun consommable.

Kuebler Group • Fritz Kuebler GmbH • Schubertstr. 47 • D-78054 Villingen-Schwenningen • Phone: +49 7720 3903-0 • info@kuebler.com • www.kuebler.com
 Service & Support: www.kuebler.com/usa/service-support.html • mail to: servicecenter@kuebler.com

R000066.0009 - Index 3

R600.039.001


Deutsch**Installationsanleitung
Drehgeber****Wichtig!**

Vor Inbetriebnahme des Gebers unbedingt lesen.


Mit diesem Geber haben Sie ein Präzisionsmessgerät erworben. Beachten Sie stets die Angaben und Hinweise des Datenblattes, um eine problemlose Funktion des Gebers zu gewährleisten und um die Garantieleistung aufrecht zu erhalten. Falls im Datenblatt nichts anderes angegeben ist, bitte folgendes unbedingt beachten:

Mechanisch:


- Der Drehgeber darf weder teilweise noch ganz zerlegt oder modifiziert werden.




- Die Welle nicht nachträglich bearbeiten (schleifen, sägen, bohren, usw.). Die Genauigkeit des Gebers und die Zuverlässigkeit von Lager und Dichtung nehmen sonst Schaden. Wir sind gerne bereit, auf Ihre Kundenwünsche einzugehen.



- Das Gerät niemals mit dem Hammer ausrichten.
- Schlagbelastungen unbedingt vermeiden.
- Drehgeberwelle nicht über die im Datenblatt angegebenen Werte belasten (weder axial noch radial).



- Drehgeber und Antriebsgerät nicht an Wellen und Flanschen starr miteinander verbinden. Benutzen Sie grundsätzlich eine Kupplung (zwischen Antriebswelle und Geberwelle, bzw. zwischen Hohlwellen-Geber-Flansch und Antriebsflansch).



Für die Gebermontage empfehlen wir Ihnen den Einsatz unserer Montagehilfen und Kupplungen (siehe Zubehör-Datenblätter).

Bitte beachten Sie die umseitig stehenden Montagehinweise!

English**Installing instructions for
rotary encoders****Important!**

It is imperative to read these instructions before setting the encoder in operation.

This encoder is a precision measuring instrument. Always observe the information and instructions of the data sheet to ensure trouble-free function and to maintain warranty claims. Unless otherwise stated in the data sheet, the following has to be absolutely observed:

Mechanical:

- It is not permissible to dismantle the encoder entirely or in part or to modify it.

- Do not alter the shaft (by grinding, sawing, drilling, etc.), otherwise the accuracy of the encoder and the dependability of bearing and gasket will suffer. We are prepared to discuss special designs.

- Never align the instrument with a hammer.
- It is imperative to avoid impact loads.
- Radial and axial load capacity as stated in the data sheet have to be observed under any circumstances.

- Do not connect encoder and drive rigidly to one another at shafts and flanges. Always use a coupling (between drive shaft and encoder shaft, or between hollow-shaft encoder flange and drive flange).


We recommend that you use our assembly aids and couplings to install the encoder (see accessory data sheets).

Please observe the installation instructions on the back page, too.


- Änderungen vorbehalten -
- Subject to changes without prior notice -

Deutsch**Montagehinweis für Geber mit Welle:**


- ① Wellen auf Versatz überprüfen.



Axialversatz/Axial offset




Radialversatz/Radial offset




Winkelfehler/Angle error

Entnehmen Sie die Werte X1, X2 und X3 dem Datenblatt der Kupplung.


- ② Kupplung während der Montage vor zu starker Biegung sowie Beschädigung schützen.
- ③ Kupplung auf den Wellen ausrichten.
- ④ Spann- oder Klemmschrauben vorsichtig anziehen.

Montagehinweise für Hohlwellengeber mit Kupplung:

Geber mit Kupplung auf Welle montieren.




Mount encoder with coupling on shaft.



Kupplung mit Antriebsflansch verschrauben



Bolt coupling to drive flange.



Klemmnabe vorsichtig anziehen



Carefully tighten clamping hub

Elektrisch:

1. Geltende Sicherheitsnormen
 - Vor Inbetriebnahme sind alle benötigten Kabeladern laut Datenblatt anzuschließen! Isolieren Sie alle nicht benötigten Enden sauber, um Kurzschlüsse zu vermeiden.
 - Bei der Konfektionierung des Gegensteckers ist eine, evtl. dem Stecker beigelegte, Anleitung zu beachten.
 - An Leitungslängen empfehlen wir:
 - bei asymmetrischer Übertragung, d.h. invertierte Signale werden nicht verwendet, max. 10 m Leitungslänge.
 - bei symmetrischer Übertragung (z.B. nach RS 422) max. 50 m Leitungslänge (Leitungslänge mit verdrehten Aderpaaren)
 - Gegenstecken am Geber nur im spannungslosen Zustand ziehen oder stecken.
 - Die richtige Betriebsspannung und den maximal zulässigen Ausgangsstrom berücksichtigen (siehe Datenblatt)!
 - Ein- bzw. Ausschalten der Betriebsspannung für den Geber und das Folgegerät muss gemeinsam erfolgen.
2. Um CE-Konformität zu erreichen, ist eine EMV-gerechte Installation Voraussetzung:
 - Als Steuerleitungen sind durchgehend geschirmte Kabel zu verwenden. Bei symmetrischer Übertragung (z.B. RS 422) muss ein Kabel mit verdrehten Aderpaaren verwendet werden. Der Kabelschirm wird idealerweise rundum (360°) über schirmbare Stecker oder kabeldurchführungen an den Geber und die Auswertung angelegt.
 - Die Schutzerde (PE) ist bevorzugt beidseitig, am Geber und an der Auswertung, impedanzarm anzulegen.
 - Bei Problemen durch Erdschleifen ist die Schutzerde (PE) auf der Geberseite aufzutrennen. Der Geber sollte hierbei gegenüber dem Antrieb elektrisch isoliert angebaut werden.
 - Die Geberleitungen sind getrennt von Leitungen mit hohem Störpegel zu verlegen.
 - An der Spannungsversorgung des Gebers sollten keine Verbraucher mit hohem Störpegel, wie z.B. Frequenzrichter, Magnetventile, Schütze etc. angeschlossen werden. Andernfalls ist für eine geeignete Spannungsfiltrierung zu sorgen.

Sicherheitshinweise:

1. Wenn anzunehmen ist, dass ein gefahrloser Betrieb nicht mehr gewährleistet ist, muss das Gerät außer Betrieb gesetzt und gegen unbeabsichtigtes Einschalten gesichert werden.
2. Wenn durch den Ausfall oder eine Fehlfunktion des Gebers eine Gefährdung von Menschen oder eine Beschädigung von Betriebseinrichtungen nicht auszuschließen ist, so muss dies durch geeignete Sicherheitsmaßnahmen wie Schutzvorrichtungen oder Endsicherer usw. verhindert werden.

Bei Missachtung der obigen Richtlinien können wir keine Garantie gewähren. Wir bitten um Verständnis.

English**Installation instructions for encoders with shaft:**

- ① Check shafts for offset.

Refer to the coupling data sheet for the values X1, X2, and X3.

- ② During assembly, protect coupling against excessive bending or damage.
- ③ Align coupling on the shafts.
- ④ Carefully tighten pulling or clamping bolts.

Installation instructions for hollow-shaft encoders with coupling:**Electrical:**




1. The existing safety devices for electrical installations have to be observed.
 - Before setting in operation, connect all required strands as per data sheet. To prevent short-circuits, neatly insulate the ends of all strands which are not required
 - When preassembling the mating connector, comply with any instructions accompanying the connector.
 - Our recommendations regarding cable lengths:
 - in case of asymmetrical transmission, i.e. inverted signals are not used, cable length max. 10 m.
 - in case of symmetrical transmission (e.g. to RS 422), cable length max. 50 m (cable with twisted pairs of wires).
 - Plug in or pull out mating connector at the encoder only when encoder is de-energized.
 - Make certain that the operating voltage is correct and the max. permissible output current is not exceeded (see data sheet).
 - The operating voltage for encoder and succeeding device must be turned on and off together.
2. In order to obtain CE-Conformity, EMC installation conformity should be observed.
 - Shielded cables should be used or control lines. In case of symmetrical transmission (e.g. RS 422) a cable with twisted pairs of wire has to be used. The cable shield should if possible be connected fully enclosed (360°) by shielded connectors or cable bushings. This has to be done at the encoder and transmission end.
 - The protection earth should be put with low impedance on both face and back of the encoder and the transmission end.
 - In case of earth loop problems, the protection earth of the encoder side has to be removed. On this occasion, the encoder should be placed electrically isolated opposite the actuation.
 - The encoder lines should run separately to cables with high noise levels.
 - Consumer with high disturbance level, e.g. frequency converters, solenoid valves, contactors etc. should not be connected to the same voltage supply. Otherwise, a suitable voltage filtering has to be installed.

Safety precautions:

1. If operation without danger can no longer be assured of some point, the unit must be shut down and secured against accidental activation.
2. If personal injury or damage to equipment is possible should the encoder fail or malfunction, this must be prevented by suitable safety precautions such as protective devices or limit switches, etc.

We can assume no warranty if the above directives are disregarded. We ask for your understanding.

8.2 Brake Solenoid CSA Certification

									
<h3>Certificate of Compliance</h3>		<h3>Supplement to Certificate of Compliance</h3>							
Certificate: 80009860	Master Contract: 155941	Certificate: 80009860	Master Contract: 155941						
Project: 80009860	Date Issued: 2019-12-11	<i>The products listed, including the latest revision described below, are eligible to be marked in accordance with the referenced Certificate.</i>							
Issued To: Hollister-Whitney Elevator Co., LLC 2603 North 24th St Quincy, Illinois, 62305 United States Attention: Brent Henderson		Product Certification History							
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Project</th> <th>Date</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>80009860</td> <td>2019-12-11</td> <td>Original certification of GT31-314 elevator brake solenoid</td> </tr> </tbody> </table>		Project	Date	Description	80009860	2019-12-11	Original certification of GT31-314 elevator brake solenoid
Project	Date	Description							
80009860	2019-12-11	Original certification of GT31-314 elevator brake solenoid							
		Issued by: <i>Kevin Chieu</i> Kevin Chieu							
CSA B44.1/ASME A17.5									
PRODUCTS CLASS - C241101 - ELEVATOR EQUIPMENT-Open and Enclosed Elevator Electrical Equipment CLASS - C241181 - ELEVATOR EQUIPMENT - Open and Enclosed Elevator Electrical Equipment - Certified to US Standards Elevator Brake solenoid GT31-314 Ratings: Pick 190Vdc, 2.5A max Hold 80Vdc, 1A max 60% duty cycle, 180 starts/hr Note: Open type equipment is investigated for use only as a component of electrical equipment where the acceptability of the final assembly is determined by CSA.									
APPLICABLE REQUIREMENTS CSA B44.1/ASME A17.5 - Elevator and Escalator Electrical Equipment									
DQD 507 Rev. 2019-04-30 © 2018 CSA Group. All rights reserved. Page 1		DQD 507 Rev. 2019-04-30 © 2018 CSA Group. All rights reserved. Page 1							