



To change Pull Through, turn the Tensioning Nut. Tighten against spring to increase Pull Through, loosen to decrease Pull Through.

When the Cable is gripped (Hammer Head down as shown) the gap between Hammer Head and Grip should be not less than 3/32" and no greater than 1/8". The corresponding gap between the Hammer Pivot and the Hammer Shaft should equal this gap, but may be greater by 1/32".

Note; if replacing the Hammer Head of a 205 or 206 Governor, parts necessary are 207-005, 207-039, & 201-019.

YOUR GOVERNOR IS:	YOUR CABLE DIAMETER IS:	HAMMER HEAD PART NUMBER	GRIP PART NUMBER	HAMMER PIVOT ASSEMBLY, 500 lb PULL THRU OR LESS	HAMMER PIVOT ASSEMBLY, 501 lb PULL THRU OR GREATER
201 or 202	3/8"	201-005	201-012	201-039-1	201-039
	7/16"	201-005-1	201-012-1		
	1/2"	201-006	201-013		
207	3/8"	207-005	205-012	207-039	207-039
208 or 209	3/8"	208-005	208-012	208-039-1	208-039
	7/16"	208-005-1	208-012-1		
	1/2"	208-006	208-013		